


Shelf Locking Device Installation

Drawer Installation Dimensions(mm)


SKW= Internal Drawer Width LW=Internal Cabinet Width
TB= Shelf Width



★ Installation for drawer with max 19mm thick drawer side


Drawer Installation Dimensions(mm)

NL= Nominal Slide Length LW=Internal Cabinet Width
TB= Shelf Width




★ Installation for drawer with max 19mm thick drawer side

Drawer Installation Dimensions(mm)




Standard Drawer Installation Dimensions(mm)

NL= Nominal Slide Length
LT = Internal cabinet Depth
 $LT_{min} = NL + 3$




Inner Drawer Installation Dimensions(mm)

NL= Nominal Slide Length



Cutting dimension of rod for Push-open synchronization(mm)

LW=Internal Cabinet Width



★ Installation for drawer with max 19mm thick drawer side


DTC
Global Quality Benchmark

Guangdong Dongtai Hardware Precision Manufacturing Co.,Ltd

Tel.: +86(0)757-25332283 Fax: +86(0)757-25551876
E-mail: dtc@dtcdtc.com Website: www.dtccltc.com


302710001-00860

Assembly



Hold the handle and push in the shelf.

Removal



Hold the handle and pull out the shelf.

For removal, Hold the handle and pull out the shelf.