




1. Insert the faucet body into the sink hole in the direction indicated by the arrow.




2. Secure the faucet to the sink by tightening the mounting screws.




3. Install the cup washer and soap dispenser along the dashed guide lines, then tighten the lock nut..




4. Connect the hot and cold water hoses to the water supply and lock securely. - Cold water: connect to the blue pipe
- Hot water: connect to the red pipe




5. Adjust the counterweight as shown, hold in position and lock securely.




6. Install the drain assembly along the dashed guide lines, then lock securely.




7. Turn on both hot and cold water, gently press the handle and let water run for about 2 minutes to flush the system.




Pull-out Spray Head The spray head is freely retractable.




Shower Spray Mode Press the switch to activate shower mode.



Aerated Stream Mode Press the switch to activate aerated mode.




Boost Spray Mode Press the switch to activate boost mode.




3. Maintenance Instructions

1. Nozzle Cleaning (Light Clogging)
Turn on the faucet and rub the nozzle to clear debris..



2. Aerator Cleaning (Reduced Flow)
Unscrew the spray head, remove and clean the aerator, then reinstall.



Post-Installation Check
1. Ensure all connections are tight and the valve handle is closed.
2. Open the main water supply and drain system, then check all connections for leaks

Cleaning Instructions
- Clean coated surfaces with a neutral soap solution, then dry thoroughly with a clean soft cloth.
- Avoid using harsh cleaners (e.g., bleach, toilet cleaners), as they may cause fine cracks on the surface.
- Do not use abrasive cleaning tools or cleaners on the faucet and accessories.