

A Strong Undermount Slide with Many Benefits Robust Components Ensure Smooth and Silent Running Action







- 7/8 extension provides a full access experience.
- Undermount slides with silent, soft, and effortless closing.
- Quick release locking device or pin-mount connection options meet application requirements.
- The redesigned cabinet member increases stablity over a lifetime of use.








Durability



Eco- Friendliness

434 www.dlodtc.com










The innovative structure of the undermount slide produces a minimal opening force for a comfortable experience. D-MOTION PLUS is widely used in bedrooms, bathrooms and other living spaces in the home.









D-MOTION PLUS, with 7/8 extension, enables full access to everything stored in a drawer.






#### **PRODUCT**




### DESCRIPTION

- Load capacity: 25kg - Finish: zinc plated
- Length: 250-600mm
- 2/3 extension
- Drawer up&down adjustment: 0~+4mm
- Tool free assembly and removal of drawer
- Silent system guarantees smooth run without noise
- Maximum drawer side thickness:16mm


# SPACE REQUIREMENT




### SOFT CLOSE DRAWER/PUSH-OPEN DRAWER










### PLANNING


DIC -DIC -

DIC \*\* 128 224

37 Fourth hole

0000 BAC =







450

500

550





	NL (mm)	A (mm)	B (mr
	250	221	18
	270 300 350	241	20
	300	271	23
334	350	321	28
	400 450 500 550 600	371	33
	450	421	38
18//	500	471	4
	550	521	48
	600	571	53

444 www.dtcdtc.com

D

# assembly and adjustment

Assembly and Adjustment
(for D-MOTION PLUS Partial Extension Undermount Slides












Fix the slide onto the cabinet.



Pull out the drawer member of the slide from the cabinet, lay the drawer onto the slide.



Press the locking pin into the drawer side to lock the position of the drawer.



For removal, pull out the locking pin from the drawer side. Lift the drawer and pull it out from the cabinet.


DTC is always innovating! For more information, please visit our website www.dtcdtc.com

452 www.dtcdtc.com





# Order Information














# Order Information







Mark the position of the locking device and fix the locking device onto the drawer bottom



Drill a hole (06, depth 10mm) mark the position of the fourth hole for standard

L.

UNDERMOUNT