

UNDERMOUNT SLIDE SERIES

**D-MOTION PLUS** 



A Strong Undermount Slide with Many Benefits Robust Components Ensure Smooth and Silent Running Action







- 7/8 extension provides a full access experience.
- Undermount slides with silent, soft, and effortless closing.
- Quick release locking device or pin-mount connection options meet application requirements.
- The redesigned cabinet member increases stablity over a lifetime of use.









urability E

ty Eco- Friendlines

434 www.dtotic.com










The innovative structure of the undermount slide produces a minimal opening force for a comfortable experience. D-MOTION PLUS is widely used in bedrooms, bathrooms and other living spaces in the home.









D-MOTION PLUS, with 7/8 extension, enables full access to everything stored in a drawer.






### **PRODUCT**



### DESCRIPTION

- Load capacity: 25kg Finish: zinc plated
- Length: 250-600mm
- 2/3 extension
- Drawer up&down adjustment: 0~+4mm - Tool free assembly and removal of drawer
- Silent system guarantees smooth
  - run without noise Maximum drawer side thickness:16mm

# SPACE REQUIREMENT





Inner drawer : LT=NL+21

## SOFT CLOSE DRAWER/PUSH-OPEN DRAWER











Push-open drawer


### PLANNING


- Cabinet edge

- 37 Fourth hole











446 www.dtcdtc.com













Fix the slide onto the cabinet.

Pull out the drawer member of the slide from the cabinet, lay the drawer onto the slide.

Press the locking pin into the drawer side to lock the position of the drawer.

Removal with Peg





For removal, pull out the locking pin from the drawer side. Lift the drawer and pull it out from the cabinet.

DTC is always innovating!
For more information, please visit our website www.dtcdtc.com

44







## Order Information














## Order Information







Mark the position of the locking device and fix the locking device onto the drawer bottom

